



FLIGHTFINS

MINIFINS



INCLUDED HARDWARE

- 6 #12-24 Phillips Panhead Screws
 - 6 KEPS Lock Nuts
-

INSTALLATION

- Install the screws into the MiniFins
- Loosely attach to the FlightFender with the lock nuts
- Install the FlightFenders onto the Onewheel
- Adjust the MiniFins to your foot and then tighten
DO NOT OVERTIGHTEN. The end of the bolt should only be 1/8" past the lock nut.
- Fly!

